

Cotonou

Tel: 64644505 /61753121

Computer Computer charger

**CHARGEUR ACER 19V / 3.42A /
65W NEUF**

Reference : TS03
Voltage: 19Volts
Ampérage: 3.42 Ampères
Watt : 65 W
Connecteur: 5.5mm * 1.7mm
Etat: Neuf
Garantie: 3 mois

Marque: Générique

ACER_ASPIRE 1410 SERIES_(Ordinateur portable)
ACER_ASPIRE 1640 SERIES_(Ordinateur portable)
ACER_ASPIRE 1640Z SERIES_(Ordinateur portable)
ACER_ASPIRE 1650 SERIES_(Ordinateur portable)
ACER_ASPIRE 1650Z SERIES_(Ordinateur portable)
ACER_ASPIRE 1690 SERIES_(Ordinateur portable)
ACER_ASPIRE 1690-D2 SERIES_(Ordinateur portable)
ACER_ASPIRE 2420 SERIES_(Ordinateur portable)
ACER_ASPIRE 2920 SERIES_(Ordinateur portable)
ACER_ASPIRE 2920Z SERIES_(Ordinateur portable)
ACER_ASPIRE 2930 SERIES_(Ordinateur portable)
ACER_ASPIRE 2930Z SERIES_(Ordinateur portable)
ACER_ASPIRE 3050 SERIES_(Ordinateur portable)
ACER_ASPIRE 3100 SERIES_(Ordinateur portable)
ACER_ASPIRE 3410 SERIES_(Ordinateur portable)
ACER_ASPIRE 3500 SERIES_(Ordinateur portable)
ACER_ASPIRE 3610 SERIES_(Ordinateur portable)
ACER_ASPIRE 3620 SERIES_(Ordinateur portable)
ACER_ASPIRE 3630 SERIES_(Ordinateur portable)
ACER_ASPIRE 3640 SERIES_(Ordinateur portable)
ACER_ASPIRE 3650 SERIES_(Ordinateur portable)
ACER_ASPIRE 3660 SERIES_(Ordinateur portable)
ACER_ASPIRE 3680 SERIES_(Ordinateur portable)
ACER_ASPIRE 3690 SERIES_(Ordinateur portable)
ACER_ASPIRE 3810T SERIES_(Ordinateur portable)
ACER_ASPIRE 3810TG SERIES_(Ordinateur portable)
ACER_ASPIRE 3810TZ SERIES_(Ordinateur portable)
ACER_ASPIRE 3810TZG SERIES_(Ordinateur portable)
ACER_ASPIRE 3935 SERIES_(Ordinateur portable)
ACER_ASPIRE 4230 SERIES_(Ordinateur portable)
ACER_ASPIRE 4235 SERIES_(Ordinateur portable)
ACER_ASPIRE 4240 SERIES_(Ordinateur portable)
ACER_ASPIRE 4310 SERIES_(Ordinateur portable)
ACER_ASPIRE 4315 SERIES_(Ordinateur portable)
ACER_ASPIRE 4320 SERIES_(Ordinateur portable)
ACER_ASPIRE 4330 SERIES_(Ordinateur portable)
ACER_ASPIRE 4336 SERIES_(Ordinateur portable)
ACER_ASPIRE 4410 SERIES_(Ordinateur portable)
ACER_ASPIRE 4530 SERIES_(Ordinateur portable)
ACER_ASPIRE 4535 SERIES_(Ordinateur portable)
ACER_ASPIRE 4535G SERIES_(Ordinateur portable)
ACER_ASPIRE 4540 SERIES_(Ordinateur portable)
ACER_ASPIRE 4540G SERIES_(Ordinateur portable)
ACER_ASPIRE 4710 SERIES_(Ordinateur portable)
ACER_ASPIRE 4710Z SERIES_(Ordinateur portable)
ACER_ASPIRE 4715Z SERIES_(Ordinateur portable)

ACER_ASPIRE 4732Z SERIES_(Ordinateur portable)
ACER_ASPIRE 4736 SERIES_(Ordinateur portable)
ACER_ASPIRE 4736-2 SERIES_(Ordinateur portable)
ACER_ASPIRE 4736G SERIES_(Ordinateur portable)
ACER_ASPIRE 4736G-2 SERIES_(Ordinateur portable)
ACER_ASPIRE 4736Z SERIES_(Ordinateur portable)
ACER_ASPIRE 4736ZG SERIES_(Ordinateur portable)
ACER_ASPIRE 4736ZG-2 SERIES_(Ordinateur portable)
ACER_ASPIRE 4810T SERIES_(Ordinateur portable)
ACER_ASPIRE 4810T-O SERIES_(Ordinateur portable)
ACER_ASPIRE 4810TG SERIES_(Ordinateur portable)
ACER_ASPIRE 4810TG-O SERIES_(Ordinateur portable)
ACER_ASPIRE 4810TZ SERIES_(Ordinateur portable)
ACER_ASPIRE 4810TZ-O SERIES_(Ordinateur portable)
ACER_ASPIRE 4810TZG SERIES_(Ordinateur portable)
ACER_ASPIRE 4810TZG-O SERIES_(Ordinateur portable)
ACER_ASPIRE 4920 SERIES_(Ordinateur portable)
ACER_ASPIRE 4930 SERIES_(Ordinateur portable)
ACER_ASPIRE 4930G SERIES_(Ordinateur portable)
ACER_ASPIRE 4935 SERIES_(Ordinateur portable)
ACER_ASPIRE 4937 SERIES_(Ordinateur portable)
ACER_ASPIRE 4937G SERIES_(Ordinateur portable)
ACER_ASPIRE 5000 SERIES_(Ordinateur portable)
ACER_ASPIRE 5050 SERIES_(Ordinateur portable)
ACER_ASPIRE 5100 SERIES_(Ordinateur portable)
ACER_ASPIRE 5220 SERIES_(Ordinateur portable)
ACER_ASPIRE 5230 SERIES_(Ordinateur portable)
ACER_ASPIRE 5235 SERIES_(Ordinateur portable)
ACER_ASPIRE 5310 SERIES_(Ordinateur portable)
ACER_ASPIRE 5315 SERIES_(Ordinateur portable)
ACER_ASPIRE 5320 SERIES_(Ordinateur portable)
ACER_ASPIRE 5330 SERIES_(Ordinateur portable)
ACER_ASPIRE 5332 SERIES_(Ordinateur portable)
ACER_ASPIRE 5335 SERIES_(Ordinateur portable)
ACER_ASPIRE 5335Z SERIES_(Ordinateur portable)
ACER_ASPIRE 5338 SERIES_(Ordinateur portable)
ACER_ASPIRE 5410 SERIES_(Ordinateur portable)
ACER_ASPIRE 5510 SERIES_(Ordinateur portable)
ACER_ASPIRE 5515 SERIES_(Ordinateur portable)
ACER_ASPIRE 5516 SERIES_(Ordinateur portable)
ACER_ASPIRE 5517 SERIES_(Ordinateur portable)
ACER_ASPIRE 5520 SERIES_(Ordinateur portable)
ACER_ASPIRE 5520G SERIES_(Ordinateur portable)
ACER_ASPIRE 5530 SERIES_(Ordinateur portable)
ACER_ASPIRE 5530G SERIES_(Ordinateur portable)
ACER_ASPIRE 5532 SERIES_(Ordinateur portable)
ACER_ASPIRE 5534 SERIES_(Ordinateur portable)
ACER_ASPIRE 5535 SERIES_(Ordinateur portable)
ACER_ASPIRE 5536 SERIES_(Ordinateur portable)
ACER_ASPIRE 5538 SERIES_(Ordinateur portable)
ACER_ASPIRE 5538G SERIES_(Ordinateur portable)
ACER_ASPIRE 5542 SERIES_(Ordinateur portable)
ACER_ASPIRE 5542G SERIES_(Ordinateur portable)
ACER_ASPIRE 5570 SERIES_(Ordinateur portable)
ACER_ASPIRE 5580 SERIES_(Ordinateur portable)

ACER_ASPIRE 5710Z SERIES_(Ordinateur portable)
ACER_ASPIRE 5715Z SERIES_(Ordinateur portable)
ACER_ASPIRE 5720 SERIES_(Ordinateur portable)
ACER_ASPIRE 5720G SERIES_(Ordinateur portable)
ACER_ASPIRE 5720Z SERIES_(Ordinateur portable)
ACER_ASPIRE 5730Z SERIES_(Ordinateur portable)
ACER_ASPIRE 5732Z SERIES_(Ordinateur portable)
ACER_ASPIRE 5732ZG SERIES_(Ordinateur portable)
ACER_ASPIRE 5735 SERIES_(Ordinateur portable)
ACER_ASPIRE 5735Z SERIES_(Ordinateur portable)
ACER_ASPIRE 5737Z SERIES_(Ordinateur portable)
ACER_ASPIRE 5738 SERIES_(Ordinateur portable)
ACER_ASPIRE 5738DG SERIES_(Ordinateur portable)
ACER_ASPIRE 5738DZG SERIES_(Ordinateur portable)
ACER_ASPIRE 5738G SERIES_(Ordinateur portable)
ACER_ASPIRE 5738PG SERIES_(Ordinateur portable)
ACER_ASPIRE 5738PZG SERIES_(Ordinateur portable)
ACER_ASPIRE 5738Z SERIES_(Ordinateur portable)
ACER_ASPIRE 5739 SERIES_(Ordinateur portable)
ACER_ASPIRE 5739G SERIES_(Ordinateur portable)
ACER_ASPIRE 5810T SERIES_(Ordinateur portable)
ACER_ASPIRE 5810TG SERIES_(Ordinateur portable)
ACER_ASPIRE 5810TZ SERIES_(Ordinateur portable)
ACER_ASPIRE 5810TZG SERIES_(Ordinateur portable)
ACER_ASPIRE 5920 SERIES_(Ordinateur portable)
ACER_ASPIRE 5930 SERIES_(Ordinateur portable)
ACER_ASPIRE 5935G SERIES_(Ordinateur portable)
ACER_ASPIRE 6530 SERIES_(Ordinateur portable)
ACER_ASPIRE 6530G SERIES_(Ordinateur portable)
ACER_ASPIRE 6920 SERIES_(Ordinateur portable)
ACER_ASPIRE 6930 SERIES_(Ordinateur portable)
ACER_ASPIRE 6930G SERIES_(Ordinateur portable)
ACER_ASPIRE 6935 SERIES_(Ordinateur portable)
ACER_ASPIRE 6935G SERIES_(Ordinateur portable)
ACER_ASPIRE 7100 SERIES_(Ordinateur portable)
ACER_ASPIRE 7230 SERIES_(Ordinateur portable)
ACER_ASPIRE 7530 SERIES_(Ordinateur portable)
ACER_ASPIRE 7530G SERIES_(Ordinateur portable)
ACER_ASPIRE 7535 SERIES_(Ordinateur portable)
ACER_ASPIRE 7540 SERIES_(Ordinateur portable)
ACER_ASPIRE 7715Z SERIES_(Ordinateur portable)
ACER_ASPIRE 7730 SERIES_(Ordinateur portable)
ACER_ASPIRE 7730G SERIES_(Ordinateur portable)
ACER_ASPIRE 7730Z SERIES_(Ordinateur portable)
ACER_ASPIRE 7735 SERIES_(Ordinateur portable)
ACER_ASPIRE 7735Z SERIES_(Ordinateur portable)
ACER_ASPIRE 7736G SERIES_(Ordinateur portable)
ACER_ASPIRE 7736Z SERIES_(Ordinateur portable)
ACER_ASPIRE 9100 SERIES_(Ordinateur portable)
ACER_EXTENSA 2300 SERIES_(Ordinateur portable)
ACER_EXTENSA 2600 SERIES_(Ordinateur portable)
ACER_EXTENSA 3000 SERIES_(Ordinateur portable)
ACER_EXTENSA 4100 SERIES_(Ordinateur portable)
ACER_EXTENSA 4100-D2 SERIES_(Ordinateur portable)
ACER_EXTENSA 4120 SERIES_(Ordinateur portable)

ACER_EXTENSA 4230 SERIES_(Ordinateur portable)
ACER_EXTENSA 4420 SERIES_(Ordinateur portable)
ACER_EXTENSA 4620 SERIES_(Ordinateur portable)
ACER_EXTENSA 4620Z SERIES_(Ordinateur portable)
ACER_EXTENSA 4630 SERIES_(Ordinateur portable)
ACER_EXTENSA 4630Z SERIES_(Ordinateur portable)
ACER_EXTENSA 5010 SERIES_(Ordinateur portable)
ACER_EXTENSA 5200 SERIES_(Ordinateur portable)
ACER_EXTENSA 5210 SERIES_(Ordinateur portable)
ACER_EXTENSA 5220 SERIES_(Ordinateur portable)
ACER_EXTENSA 5230 SERIES_(Ordinateur portable)
ACER_EXTENSA 5230E SERIES_(Ordinateur portable)
ACER_EXTENSA 5420 SERIES_(Ordinateur portable)
ACER_EXTENSA 5430 SERIES_(Ordinateur portable)
ACER_EXTENSA 5510Z SERIES_(Ordinateur portable)
ACER_EXTENSA 5610 SERIES_(Ordinateur portable)
ACER_EXTENSA 5620 SERIES_(Ordinateur portable)
ACER_EXTENSA 5620Z SERIES_(Ordinateur portable)
ACER_EXTENSA 5630 SERIES_(Ordinateur portable)
ACER_EXTENSA 5630EZ SERIES_(Ordinateur portable)
ACER_EXTENSA 5630Z SERIES_(Ordinateur portable)
ACER_EXTENSA 5635 SERIES_(Ordinateur portable)
ACER_EXTENSA 5635ZG SERIES_(Ordinateur portable)
ACER_EXTENSA 5735G SERIES_(Ordinateur portable)
ACER_EXTENSA 7230 SERIES_(Ordinateur portable)
ACER_EXTENSA 7230E SERIES_(Ordinateur portable)
ACER_EXTENSA 7630 SERIES_(Ordinateur portable)
ACER_EXTENSA 7630EZ SERIES_(Ordinateur portable)
ACER_EXTENSA 7630Z SERIES_(Ordinateur portable)
ACER_FERRARI 1000 SERIES_(Ordinateur portable)
ACER_FERRARI 1100 SERIES_(Ordinateur portable)
ACER_FERRARI 1200 SERIES_(Ordinateur portable)
ACER_FERRARI ONE 200 SERIES_(Netbook)
ACER_TRAVELMATE 2300 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 2310 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 2410 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 2420 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 2430 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 2440 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 2460 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 2480 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 2490 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 3000 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 3010 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 3020 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 3040 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 3200 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 3260 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 3270 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 370 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 380 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 4000 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 4020 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 4050 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 4060 SERIES_(Ordinateur portable)

ACER_TRAVELMATE 4100-D2 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 4320 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 4330 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 4335 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 4500 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 4520 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 4530 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 4600 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 4600-D2 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 4720 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 4730 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 4730G SERIES_(Ordinateur portable)
ACER_TRAVELMATE 5100 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 5210 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 5230 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 5310 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 5320 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 5330 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 5520 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 5530 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 5600 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 5610 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 5710 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 5720 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 5730 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 6000 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 6252 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 6292 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 6452 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 6492 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 6493 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 6552 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 6592 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 7330 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 7530 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 7530G SERIES_(Ordinateur portable)
ACER_TRAVELMATE 7730 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 7730G SERIES_(Ordinateur portable)
ACER_TRAVELMATE 8000 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 8100 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 8331 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 8571 SERIES_(Ordinateur portable)
ACER_TRAVELMATE 8571G SERIES_(Ordinateur portable)
ACER_TRAVELMATE C200 SERIES_(Ordinateur portable)
ACER_TRAVELMATE C300 SERIES_(Ordinateur portable)
ACER_TRAVELMATE C310 SERIES_(Ordinateur portable)
EMACHINES_D520 SERIES_(Ordinateur portable)
EMACHINES_D620 SERIES_(Ordinateur portable)
EMACHINES_D720 SERIES_(Ordinateur portable)
EMACHINES_D725 SERIES_(Ordinateur portable)
EMACHINES_E510 SERIES_(Ordinateur portable)
EMACHINES_E520 SERIES_(Ordinateur portable)
EMACHINES_E525 SERIES_(Ordinateur portable)
EMACHINES_E620 SERIES_(Ordinateur portable)
EMACHINES_E625 SERIES_(Ordinateur portable)

EMACHINES_E720 SERIES_(Ordinateur portable)
EMACHINES_E725 SERIES_(Ordinateur portable)
EMACHINES_G420 SERIES_(Ordinateur portable)
EMACHINES_G520 SERIES_(Ordinateur portable)
EMACHINES_G525 SERIES_(Ordinateur portable)
EMACHINES_G620 SERIES_(Ordinateur portable)
EMACHINES_G625 SERIES_(Ordinateur portable)
EMACHINES_G627 SERIES_(Ordinateur portable)
EMACHINES_G720 SERIES_(Ordinateur portable)
EMACHINES_G725 SERIES_(Ordinateur portable)
PACKARD BELL_EASYNOTE LJ61 SERIES_(Ordinateur portable)
PACKARD BELL_EASYNOTE LJ63 SERIES_(Ordinateur portable)

Pour obtenir un devis de commande, veuillez vous rendre chez ETS. IEIRAM

Le devis est valable un mois. Dès sa signature, nous vous garantissons une livraison dans les 15 jours.

ETABLISSEMENT IEIRAM

Importateur de matériels informatiques en provenance de la France

Domicilié au C/501 Fignonhou Godomey - Gare (quartier communément appelé Adignon gon ou chez le délégué)

Voir condition générale de vente d' IEIRAM (CGV - IEIRAM) ci-dessous

<http://big-affaires.com/page/view/1241/c2865b/CHARGEUR+ACER+19V+%2F+3.42A+%2F+65W+NEUF?hc=BJ>